



Note:
 4798-Idler Roll with Bearing Copper
 4776-Drive Shaft Copper
 4021-Depth Gauge Copper

P/N 4598 Front bearing welded to wear plate

1034 / 1039

1039-66

Parts List

5/19/2006

Part #	Quantity per Machine	Description
4021	1	Groove Depth Gauge
4026	1	Setup Gage Chip
4257	1	Housing
4259	1	Top Plate
4261	1	Spindle Lock Retainer
4273	1	Gear Cover
4287	1	Slide
4297	1	Hand Crank Ratchet ½" Drive w/ Socket
4589	1	Spindle Lock
4590	1	Lead Screw
4596	1	Drive Shaft Rear Bearing
4598	1	Drive Shaft Front Bearing & Face Plate
4611	1	Idler Shaft
4612	1	Idler Roll Bearing
4618	1	Pinion Shaft
4619	1	Pinion Key
4620	1	Pinion Gear
4621	1	Drive Gear
4622	1	Bronze Bushing
4776	1	Drive Shaft / 1034
4793	1	Idler Roll
4798	1	Idler Roll / Copper
4799	1	Drive Shaft / 1039
4800	1	Drive Shaft / Copper
	1	⅛" x 2" Roll Pin
	2	3/8 - 16 x 1 ½" SHCS
	2	¼-20 x 2" BHCS
	2	⅜" Steel Ball
	2	1"-14 Hex Jam Nut
	4	¼-20 x ½" FHCS
	2	¼-20 x ½" BHCS
	4	¼-20 x ⅜" BHCS
	2	¼-28 Grease Zerk
	1	#2 x ¼ Type U-Drive Screw

DISTRIBUTED BY: